


DANDY Decorators Tools Instructions for use


Antisplatter Roller



To assemble the Roller for use.

Position the handle between the lugs and slide on in the direction of the arrow.

To remove the handle just reverse this procedure.



Cleaning the Sleeve with a Dandy Roller Cleaner.

To remove the Roller Sleeve for cleaning, lever the frame in the direction of arrow 1 and lift the sleeve out of the guard in the direction of arrow 2.



To clean the Roller Sleeve with the Dandy Roller Cleaner.

Remove the end caps in the direction of arrow 3 and clean as instructed with the Dandy Roller Cleaner.

To get the most from you Antisplatter Roller visit our video section at

<http://www.handysolutionsuk.com/Videos.html>

TWO YEAR WARRANTY

DANDY products carry a TWO YEAR WARRANTY against defective workmanship and materials. Should your Dandy Paint Brush or Roller Cleaner fail please contact us at the address below about our replacement policy. This guarantee is offered in addition to and does not diminish your statutory rights. Please note the products are guaranteed for normal use but NOT against misuse.

Additional Cleaners may be obtained from: DBT Manufacturing 7 Islay Gardens, Portsmouth, Hampshire PO6 3UF
England

Tel: 02392 384549
Email: sales@handysolutionsuk.com

Fax: 0870 458 6721
Website: www.handysolutionsuk.com